


DesCAD V6.2



What's new



New Features

- New Machine Monitoring function that lets you keep an eye on the machine remotely. Complete machine status can be visualized including remaining time to run.
 - New user group function to separate work data into Nodes with a Tree view including selectable “Drag and Drop” function between Tree Nodes.
 - New settings options for the end of cycle such as Auto Homing.
 - Ability to rename the measure curve attributes, default is F,X,Y,Z.
 - New settings capability, for all Log and Error files.
-

Improvements

- Graphical user interface with Korean language
- Improved safety plane management in 3D modes.
- Improved full auto cutter calibration.
- Added warning message when user rotates to an uncalibrated tool position.
- Improved the interface with the HT400.
- Improved file import in DesCAD-SCAN.
- Operators User Interface simplified and improved

and much more...
